



**Landscaper Series
HydroSeeding Systems**

Jet Agitation MIXING INSTRUCTIONS

- 1.) Check fuel and engine oil levels and fill if necessary.
- 2.) Make sure all ball valves are closed.
- 3.) Start engine and allow to warm up.
- 4.) Fill the tank with water until 3/4 full.
- 5.) Open the ball valves to run clear water through the hoses to help reduce the risk of clogs.
- 6.) Turn off the valves and start loading your materials
- 7.) Load materials into the tank in the following order.
 - Load all soluble or liquid nutrients and growth enhancers such as fertilizer, lime, biostimulant, etc.
 - Load Dye if desired.
 - Load 1/2 of the Mulch.
 - Load the Seed.
 - Load Moisture Retention Polymers and Tackifiers
 - Load the remainder of the Mulch.
- 8.) Top off with water and continue mixing until thoroughly mixed.
- 9.) You are now ready to spray.
- 10.) Once you are done spraying, fill with 1/4 tank of water and flush the pump and hoses.
- 11.) If you have additional tanks to spray, repeat process starting with step #4.
- 12.) If you are done for the day, remove the drain plug and drain everything out of the tank, pump, hoses, etc.